



TRENDS BED INSTRUCTIONS

Queen & King Size

Please follow the instructions carefully.

Failure to follow the assembly instructions may cause damage to your bed.

Bolt Bag includes

4 x 60mm bolts & washes

2 x 100mm Bolts with 2 washes & 2 nuts

6 x Bed frame assembly kits

1 x Spanner

64 bed slat shoes

4 x 50 mm Bolts and washes for Legs

1. Take the end of the Bed Frame which have the bolt holes for the headboard
2. Screw in the 3 threaded connector bolts
3. Slide on the centre bed rail and bolt in place
4. Slide on the 2 side rails and bolt in place
5. Repeat for the tail end of the bed
6. Lift up the Bed and bolt in your chosen legs with the
7. 50 mm bolts that are attached and fully tighten with the spanner supplied
8. Take the headboard and carefully bolt it to the end beam using the 2 x 100mm bolts
9. The remaining 4 x 60mm bolts and washes can now be screwed into the main rail
10. Attach rubber shoes to the centre beam
11. Slide in flexible slat
12. Attach outer shoes

TOUCHWOOD PRODUCTIONS LTD

Head Office: 74 Main Road, Tawa, PO Box 22018, Wellington, New Zealand

Phone: +64 4 232 2275 Fax: +64 4 232 2276

Email: info@touchwoodcots.co.nz Website: www.touchwoodcots.co.nz