



...a touch of New Zealand

CONGRATULATIONS!!

YOU ARE NOW A PROUD OWNER OF A QUALITY PIECE OF TOUCHWOOD FURNITURE.

All of our products are hand crafted from sustainable, renewable New Zealand Pine Timber. By using the skills of our craftsmen, we have produced the finest pieces of quality furniture that will bring pleasure to you for years to come.

FURNITURE CARE INSTRUCTIONS

All furniture requires some care to keep its appearance. Please read the following care instructions:

1. Please note that by exposing the wooden furniture to extreme conditions, such as excessive heat or direct sunlight, this may influence the product's durability and may cause cracking and deterioration of the colour.

It is important to remember that timber is a natural product and if not maintained properly it may affect the quality of your furniture.

2. For general cleaning, use a duster or damp cloth. To remove marks, a mild soap solution can be used. Please Note: Strong abrasive household cleaners will damage the timber surface.
3. Wooden furniture must always be protected from hot liquids and strong cleaning agents. Avoid contact with sharp or heavy objects by using table mats or cloths to protect surfaces.
4. As careful as you may be, accidents do happen. For any spills, act quickly to reduce the possibility of damage. Gently wipe up the spill immediately with a slightly damp, soft cloth. Then wipe dry using a clean, soft cloth in the direction of the wood grain.
5. Toy/Storage Chest – WARNING, forced closure of toy box lid may result in damage to the closure mechanism. To ensure safety of toy box content please do not force the lid closed, let it close gradually as designed.
6. Do not open more than one drawer at a time (it can be hazardous to young children, if they decide to climb)
7. When moving furniture, whether it's across the country or only across the room, special care must always be taken to prevent any damage. We strongly recommend when moving, that you lift and place your furniture rather than sliding or dragging the pieces across the floor, as this may cause damage to the joints. As some of our furniture items are heavy, you may need two people to lift.
8. For all of our Nursery Cots and Change Tables, we recommend that all bolts should occasionally be checked to ensure that they are securely tightened.
9. Touchwood furniture comes with a 5 year manufacturer's guarantee as testimony to the quality and longevity of our range. This warranty covers faulty materials and workmanship, however does not include general wear and tear or damage caused by the product not being used in accordance to the above guidelines.



WE BELIEVE FURNITURE SHOULD BE MADE TO
LAST A LIFETIME, SO WE HOPE THAT YOU ENJOY
THIS PIECE OF FURNITURE, AS MUCH AS WE HAVE
ENJOYED HANDCRAFTING IT FOR YOU.

TouchwoodNZ



Touchwood_NZ



TouchwoodNZ



TOUCHWOOD PRODUCTIONS LTD

74 Main Road, Tawa, PO Box 22018,
Wellington 5028, New Zealand

Phone: +64 4 232 2275 Fax: +64 4 232 2276

Email: info@touchwoodcots.co.nz

Website: www.touchwoodcots.co.nz